
## ASSEMBLY INSTRUCTIONS FOR YOUR

## MASON TABLE LAMP



## IMPORTANT SAFETY INSTRUCTIONS

- \*This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce risk of electric shock. \*This plug will fit in a polarized outlet only one way. If it does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. DO NOT ALTER THE PLUG.
- \*Turn the power off (remove electrical plug from outlet) before replacing light bulb, making sure the bulb has cooled.
- \*Do not subject the lamp to any shock while lit as shattering of bulb may result.

## ASSEMBLY INSTRUCTIONS:

NOTE: Do not connect the electricity until lamp is fully assembled.

- 1. Remove all parts from carton. Do not throw away any parts.
- 2. Place the lamp base on level surface.
- 3. Remove finial (A) from harp (C).
- 4. Squeeze harp (C) inward and place into the opening of saddle (D).
- 5. Place shade (B) onto harp (C).
- 6. Screw finial (A) onto harp (C) to secure the shade to the lamp.
- 7. Insert one (1) 150W MAX. Type A, Medium Base bulb into the socket.
- 8. Remove protective plastic (F) from polarized plug (E). Insert polarized plug (E) into wall outlet.
- \* To clean, use a soft cloth only. Do not use any chemical or abrasive cleaners.