


# ASSEMBLY INSTRUCTIONS FOR YOUR WILLIAMSBURG FINNIE FLOOR LAMP



## IMPORTANT SAFETY INSTRUCTIONS:

- \* This lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If it does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do NOT alter the plug.
- \* Do not use with an extension cord unless the plug from the lamp can be fully inserted into the extension cord receptical.
- \* Switch power off and remove plug from the wall outlet before replacing the bulb.
- \* This lamp is UL rated for dry locations.

## ASSEMBLY INSTRUCTIONS:

1. Unpack all parts and place them on a level surface.
2. Align column (E) with base (G). Place threaded tube (F) through hole in the center of base (G). Pull cord taut from below base (G) to prevent damage to the wire.
3. Hold column (E) and base (G) together and carefully turn the lamp onto its side. Slide washer (H) onto threaded tube (F). Thread nut (I) onto tube (F) and tighten with wrench (J).
4. Carefully turn lamp into upright position.
5. Remove finial (A) from harp (C).
6. Squeeze harp (C) inward and place into the opening of saddle (D).
7. Place shade (B) onto harp (C).
8. Screw finial (A) onto harp (C) to secure shade to lamp.
9. Install one (1) 150W MAX. Type A bulb into socket.
10. Remove protective plastic from polarized plug (K).
11. Insert polarized plug (K) into wall outlet.

\* To clean, use a soft cloth only. Do not use any chemical or abrasive cleaners. \*